

JBC

www.jbctools.com

INSTRUCTION MANUAL



MV

Pneumatic Desoldering Module
for DI

This manual corresponds to the following reference:

MV-A

Packing List

The following items are included:



Pneumatic Desoldering Module 1 unit



Module Cable Connector 1 unit
Ref. 0026830



Suction Filter 1 unit
Ref. MS20



Paper Filters 1 unit
Ref. MS40
Ref. contains 50 filters



Cotton Filters 1 unit
Ref. MS30
Ref. contains 10 filters





Exhaust Filter Kit 1 unit
Ref. MV010



Manual 1 unit
Ref. 0027990

Features and Connections




Module	Stand	Tool	Tips Range	Control Units	
				CD	DI
MV	DSS	DS360	C360	●	●
	DRS	DR560	C560		●

Maintenance

Before carrying out maintenance, always unplug the electric and pneumatic connectors.

- Use a damp cloth to keep the casing clean.
- Periodically check all cable and tube connections.
- Keep filters clean to ensure proper solder suction and replace them when necessary.

Important: Do not use sharp pointed objects to open the suction filter.



- Use original JBC spare parts only
- Replace any defective or damaged pieces. Only use original JBC spare parts.
- Repairs should only be performed by a JBC authorized technical service.
- Maintenance must not be carried out by children unless supervised.

Removing Pneumatic Tubing

Push the release ring to remove the pneumatic tubing.



Safety



It is imperative to follow safety guidelines to prevent electric shock, injury, fire or explosion.

- Do not use the units for any purpose other than soldering or rework. Incorrect use may cause a fire.
- The power cord must be plugged into approved bases. Be sure that it is properly grounded before use. When unplugging it, hold the plug, not the wire.
- Do not work on electrically live parts.
- The tool should be placed in the stand when not in use in order to activate the sleep mode. The soldering tip or nozzle, the metal part of the tool and the stand may still be hot even when the station is turned off. Handle with care, including when adjusting the stand position.
- Do not leave the appliance unattended when it is on.
- Do not cover the ventilation grills. Heat can cause inflammable products to ignite.
- Avoid flux coming into contact with skin or eyes to prevent irritation.
- Be careful with the fumes produced when soldering.
- Keep your workplace clean and tidy. Wear appropriate protection glasses and gloves when working to avoid personal harm.
- Utmost care must be taken with liquid tin waste which can cause burns.
- This appliance can be used by children over the age of eight and also people with reduced physical, sensory or mental capabilities or lack of experience provided that they have been given adequate supervision or instruction concerning the use of the appliance and understand the hazards involved. Children must not play with the appliance.
- Maintenance must not be carried out by children unless supervised.

Specifications

MV

Pneumatic Desoldering Module for DI

Ref.: **MV-A**

- Net Weight: 679 g / 1.50 lb
- Module Dimensions: 225 x 145 x 55 mm / 8.86 x 5.71 x 2.17 in
- Air Pressure Supply Range: 4 - 6 Bar
- Vacuum at 6 Bar: 90% / 680 mmHg / 26.8 inHg
- Flow Rate: 15 SLPM
- Ambient Operating Temperature: 10 - 40 °C / 50 - 104 °F
- Pedal connection

- Total Package Dimension / Weight: 280 x 195 x 115 mm / 982 g
(L x W x H) 11.02 x 7.68 x 4.53 in / 2.16 lb

Complies with CE standards.
ESD safe.

JBC

Warranty

JBC's 2 year warranty covers this equipment against all manufacturing defects, including the replacement of defective parts and labor.

Warranty does not cover product wear or misuse.

In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased.



This product should not be thrown in the garbage.

In accordance with the European directive 2012/19/EU, electronic equipment at the end of its life must be collected and returned to an authorized recycling facility.

